







**VOLA HV1, HV3, HV4**



Fitting instruction  
 Montageanleitung  
 Monteringsvejledning  
 Monteringsvægledning  
 Montage hanleiding  
 Manuel de montage

 **GODKENDT  
 TIL DRILLEKVED**  
 HV1, HV3:  
 04/00020  
 04/00028




HV1, HV3	L	H	h
Std.:	114 mm 4 1/2"	120 mm 4 3/4"	27 mm 1"
+30:	114 mm 4 1/2"	150 mm 6"	56 mm 2 1/4"
/150:	150 mm 6"	120 mm 4 3/4"	27 mm 1"
+30/150:	150 mm 6"	150 mm 6"	56 mm 2 1/4"
+170:	114 mm 4 1/2"	290 mm 11 1/2"	197 mm 7 3/4"
+170/150:	150 mm 6"	290 mm 11 1/2"	197 mm 7 3/4"





5

HV1L/HV1M  
HV3L/HV3M  
HV4L/HV4M



5



**Data, 3 Bar/43.5 Psi:**

Max.	l/min.	Gal/min.	Note.
HV1/3:	5.0	1.3	Standard
HV1/3:	4.5	1.2	Standard USA
HV1/3:	9.0	1.8	Standard Japan
HV4	9,0	1.8	

Max. 70°C, 158°F



HV1




HV3




HV4





- VR277K: VR22, VR269, VR277
- \*VR17L4K: VR15P, VR16L4, VR17L (US-Standard)
- \*VR17L5K: VR15P, VR16L5, VR17L (Standard)
- \*VR17L9K: VR15P, VR16L9, VR17L (Japan Standard)
- \*VR17LSK: VR15P, VR16LS, VR17L
- VR297/L/M: VR20, VR22, VR269, VR273/L/M, VR277, VR294, VR295, VR296
- VR433: VR261, VR263, VR440, VR442, 2xVR444
- NR.10/L/M: VR20, VR22, VR273/L/M, VR294, VR295



**vola**  
 Lunavej 2  
 DK-8700 Horsens  
 Tlf : + 45 7023 5500  
 sales@vola.com  
 www.vola.com

## VOLA HV1

Date  
Okt. 16

Rev.  
6

Sheet  
SB 21.1